



Briggs and Stratton 675 Series Repair Muffler Replacement

This guide shows how to remove your muffler for replacement or cleaning.

Written By: Brad Wash



INTRODUCTION

Follow these steps to remove the muffler from your engine. Once removed, a damaged muffler can be replaced or a dirty one cleaned. The muffler can become dirty or damaged over time. It is important to keep it clear of debris so that the exhaust coming from the engine can flow normally. Once removed, a damaged muffler can be replaced or a dirty one cleaned.



TOOLS:

- [8" Needle Nose Plier](#) (1)
 - [Socket Wrench](#) (1)
 - [7/16" Socket](#) (1)
 - [1/4" Socket](#) (1)
-

Step 1 — Muffler



⚠ Make sure the the engine is off and the spark plug wire is removed and away from the spark plug before beginning.

- Use a socket wrench with a 1/4" hex bit or a 1/4" wrench to remove the three 13mm screws holding the outer flange.
- Remove the flange.

Step 2



- Use a pair of needle nose pliers to bend back the two metal tabs on ether side of the remaining screws. Be careful not to break off the tabs.

Step 3



- Use a socket wrench with a 7/16" hex bit or 7/16" wrench to remove the two remaining 75mm screws.
- ⓘ Make sure not to lose the metal bar linking the two screws.

Step 4



- Remove the muffler from the engine block by simply pulling it away.
- ⓘ After removing the muffler, make sure to note the configuration of the washer assembly that sits between the muffler and the engine block (shown in photo 2). This piece will be free to fall out once the muffler is removed. Do not lose this piece.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-02 04:34:30 AM.